

# DoorMaster™ Installation Checklist

## *Pre-Install:*

- Compatible TorqueMaster™ Center Gear, Flag Angles, End Brackets.
- Properly counter-balanced door.
- Mounting surface of Power Head Anchor Pad (spring pad) flush with header.

## *Installation:*

- Attach Cable Snubbers to TorqueMaster™ end brackets - LH & RH
- Install Locks to horizontal angles - LH & RH
- Mount operator Center Bracket to spring pad (1 lag screw).
- Assemble, level and fasten Power Head (screw cover, 2 lag screws).
- Remove Emergency Disconnect Retention Clip.
- Route emergency disconnect Cable, attach Handle and mount Handle Bracket.
- Model BIRW-2000 only: Install and connect Photoelectric Sensors.
- Mount Wall Station, assemble circuit board, battery, cover and reference card.
- Mount Light Fixture bracket, housing, bulbs and diffusers.
- Route and fasten Interface Cable (phone cord) and Cover.
- Apply Entrapment Warning Label and Emergency Disconnect Label.
- Plug in Battery, Interface Cable, and Light Fixture.
- Manually raise and lower door to verify freedom of movement.
- Verify Wall Station and Remotes are programmed to Radio receiver.
- Run Install Routine - door must start in connected and closed position.
- Perform Contact Obstruction Test.
- Model BIRW-2000 only: Perform Photoelectric Obstruction Test.
- Save the DoorMaster™ Manual.