

L-BRACKET INSTALLATION FOR TORSION I-DRIVE

Installation Instructions

P.O. Box 67 Mt. Hope, OH 44660

© 2008 Wayne-Dalton Corp. Part No. 339584 New 9/9/2008

This insert is to be used in conjunction with the main installation instructions and owner's manual.
This insert is for Torsion I-Drives Only!

www.wayne-dalton.com

Tools Needed:

Step Ladder

Drill with 3/16" bit

7/16" Socket Driver

Position mounting bracket over threaded studs and hand tighten with the (2) 5/16" X 18 hex nuts and (2) lock washers. (See Figure 1)

Secure the mounting bracket to the mounting surface by first pre-drilling the lag screw locations with a 3/16" diameter bit and fastening with (2) 5/16" x 1-5/8" lag screws. (See Figure 2)

NOTE: Ensure right side lag is at the bottom of the right side slot.

