

Drum Wraps

TorqueMaster™ Counterbalance System Installation Instructions Insert

Use this insert in conjunction with the main door installation instructions and owner's manual.

Drum Wrap Installation

Drum wraps are now supplied with the TorqueMaster™ counterbalance system.

Drum wraps are identified as right and left. To install, place the drum wrap over the cable drum and under the idrive™ disconnect cable (if installed). Align the outside flange over the outside edge of the cable drum and push the drum wrap down onto the cable drum. (See figures)

IMPORTANT! Right and left hand are always determined from inside the building looking out.

