

Wayne Dalton, a division of Overhead Door Corporation  
P.O. Box 67  
Mt. Hope, OH 44660  
www.Wayne-Dalton.com

Use this insert in conjunction with the main door installation instructions and owner's manual.

**NOTE:** All WayneMark™ 8200 doors 14'-0" to 16'-0" wide, 6'-0" to 7'-0" high (4 section high only) are now supplied with a 2" U-Bar for the top of the bottom section.

Place the 2" U-Bar on the section against the bottom of the hinges. Fasten U-Bar to each stile using (2) 1/4" - 20 x 7/8" self drilling screws.

