

# Operator Bracket

## Model: 9700

### Installation Instructions Insert

Use this insert in conjunction with the main door Installation Instructions and Owners Manual.

**NOTE:** Operator bracket must be mounted and secured prior to installing top section.

**NOTE:** The top section can be identified by no end or center hinges on the section.

**IMPORTANT!** WHEN CONNECTING A TROLLEY TYPE GARAGE DOOR OPENER TO THIS DOOR, A WAYNE -DALTON OPENER / TROLLEY BRACKET MUST BE SECURELY ATTACHED TO THE TOP SECTION OF THE DOOR, ALONG WITH ANY STRUTS PROVIDED WITH THE DOOR. THE INSTALLATION OF THE OPENER MUST BE ACCORDING TO MANUFACTURER 'S INSTRUCTIONS AND FORCE SETTINGS MUST BE ADJUSTED PROPERLY.

Locate the center of the top section and seat the operator bracket on male part of top section. The operator bracket must be centered and positioned on the top section so it bridges the transition point of the section thickness. Attach the operator bracket using (2) (#12 x 1/2") phillips pan head screws and (6) (1/4" - 20 x 11/16") self-drilling screws, as shown.

