

Styleline Inserts Installation Instructions

INSTALLING THE STYLELINE INSERTS

► Step 1

To install a Styleline insert, bow the center of the insert out toward you and slide the upper corners between the outside frame and glass (See Figure 1). Slide the insert up as far as possible, keeping the corners engaged between the frame and glass.

► Step 2

Now proceed to bend each bottom corner of the insert inward and slide between the frame and glass (See Figure 2).

► Step 3

Starting across the top and then working down the sides of the insert, work the edges of the insert in between the frame and glass. Finish by working the bottom edge of the insert into place.

