

# Strut Installation Instructions

## Waynegard™ Series

Wayne Dalton, a division of Overhead Door Corporation  
P.O. Box 67  
Mt. Hope, OH 44660  
www.Wayne-Dalton.com

This kit provides (3) struts for 4 section high doors and (4) struts for 5 section high doors. These struts are intended to be placed on the bottom and intermediate sections only. The top section is provided with a factory installed strut.

Center the strut on the lower side of the section's upper rib. Attach the strut to the rib using #8 x 1/2" self tapping screws. Alternate screw mounting along the length of the strut as shown below.

