



Wayne-Dalton Corp.
P.O. Box 67 Mt. Hope, OH 44660
(888) 827-3667
www.wayne-dalton.com

Programming HomeLink® to Quantum® or Classicdrive®

NOTE: This step can only be done on automobiles equipped with the HomeLink® System.

CAUTION: WITH THE DOOR IN THE CLOSED POSITION, PULL THE EMERGENCY DISCONNECT HANDLE TO DISENGAGE THE TROLLEY LATCH FROM THE TROLLEY.

NOTICE: Programming HomeLink® requires Wayne-Dalton transmitter that is programmed to the opener.

ATTENTION: Use the programming instructions provided with your vehicle first. Follow these instructions if the HomeLink® unit does not learn the transmitter, by using the vehicles instructions.

NOTE: If Primary Procedure does not work then use the Alternate Procedure.

Primary Procedure

Programming a HomeLink® compatible Quantum® or Classicdrive®

Opens with YELLOW antenna wires are compatible with all HomeLink® units.

Required Items

- HomeLink® Compatible Wayne-Dalton Transmitter (MODEL: 3BTM-xxx must have "U", "A", "C", or "R" in model number)
- HomeLink® Compatible opener Motor Control board (has yellow antenna wire)
- HomeLink® Equipped Automobile

PRECAUTIONS

During programming the garage door may operate. Pull the Manual Disconnect to put the operator in the disengaged position (see Step 1 below). Make sure people and objects are out of the way of the moving door to prevent potential harm or damage. Read entire process prior to starting.

Programming Training HomeLink® Unit

1. Pull the Manual Disconnect to put the opener in the disengaged position.
2. Verify the HomeLink® unit has an empty channel – press the desired HomeLink® button and observe the indicator light– if it flashes slowly, the channel is empty and ready for programming. If pressing the desired channel/button causes the indicator light to blink rapidly, or come on without blinking this channel is already programmed. You either need to choose a different channel/button on the HomeLink®, or perform Step 3 below.
3. **OPTIONAL** – To completely clear all channels on the HomeLink® unit, press and hold the two outside buttons on the HomeLink® unit until the HomeLink® indicator light begins to flash rapidly (approx. 20 seconds), then release both buttons. (Do not perform this step to train additional hand-held transmitters.) **Note:** This operation erases all previously learned transmitters and you will need to re-teach any other transmitters to your HomeLink® unit.
4. Hold the end of the Wayne-Dalton hand-held transmitter approximately 1 to 3 inches away from the HomeLink® surface – keeping the HomeLink® indicator light in view.
5. Press and hold the desired HomeLink® channel/button –indicator light should flash slowly (indicating empty channel). Continue holding the HomeLink® button, and press and hold the large button ("U" Models) or desired button "A", "C" or "R" models) on the Wayne-Dalton transmitter for approximately 3-5 seconds. The HomeLink® indicator light should now blink rapidly, indicating a successful learn operation. Release both buttons. Verify transmitter has been learned by pressing the HomeLink® button used to learn the transmitter; HomeLink® indicator light will come on without flashing or flash rapidly indicating a successful learn. Proceed to step 6 below. **Note:** If this procedure is unsuccessful perform Alternate procedure.

Teaching HomeLink® to the opener

6. Press and release the program switch on the opener. The red program status light on the opener and light will turn on and remain lit for one minute, indicating that it is ready to learn.
7. Press the HomeLink® button used in Step 5 above for 1 to 3 seconds. The program status light and convenience light on the opener will turn on and off three times indicating a successful learn.
8. Press the HomeLink® button once more to operate the door. The opener will activate and the trolley will travel towards open, the next activation will cause the trolley to travel to the closed position and reengage, subsequent operations will move the door.

Alternate Procedure

Programming a HomeLink® compatible Quantum® or Classicdrive®

Opens with YELLOW or WHITE antenna wires are compatible with all HomeLink® units.

Required Items

- HomeLink® Compatible Wayne-Dalton Transmitter (MODEL: 3BTM-xxx must have "U", "A", "C", or "R" in model number)
- HomeLink® Compatible Opener Motor Control board (has yellow or white antenna wire)
- HomeLink® Equipped Automobile

PRECAUTIONS

During programming the garage door may operate. Pull the Manual Disconnect to put the opener in the disengaged position (see Step 1 below). Make sure people and objects are out of the way of the moving door to prevent potential harm or damage. Read entire process prior to starting.

Programming Training HomeLink® Unit

1. Pull the Manual Disconnect to put the opener in the disengaged position.
2. Press and hold the two outside buttons on the HomeLink® unit until the HomeLink® indicator light begins to flash rapidly (approx. 20 seconds), then release both buttons. (Do not perform this step to train additional hand-held transmitters.) **Note:** This operation erases all previously learned transmitters and that you need to re-teach any other transmitters to your HomeLink® unit by repeating steps 3 - 6 below.
3. Hold the end of the Wayne-Dalton hand-held transmitter approximately 1 to 3 inches away from the HomeLink® surface – keeping the HomeLink® indicator light in view.
4. Press and hold the Wayne-Dalton hand-held transmitter's large center button. The transmitter's red indicator light will turn on. After 10 seconds the red indicator light will blink rapidly. Do not release the button and proceed to the next step.
5. Press the desired HomeLink® button. Do not release either button until step 6 has been completed. **Note:** It is important to immediately press the HomeLink® button as soon as the transmitter's red indicator light blinks. If the red indicator light subsequently turns on or off ignore it, this is normal.
6. The HomeLink® indicator light will be blinking during the training operation. When the HomeLink® indicator light flashes rapidly or turns off (approx. 5 to 60 seconds), both buttons may be released. The HomeLink® indicator light flashing rapidly or turning off indicates successful programming of the new frequency signal. Verify transmitter has been learned by pressing the HomeLink® button used to learn the transmitter; HomeLink® indicator light will come on without flashing or flash rapidly indicating a successful learn.

Teaching HomeLink® to the opener

7. Press the program switch on the opener. The red program status light on the opener and light will turn on and remain lit for one minute, indicating that it is ready to learn.
8. Press the HomeLink® button used in Step 5 above for 1 to 3 seconds. The program status light on the opener will turn on and off three times indicating a successful learn.
9. Press the HomeLink® the opener will activate and the trolley will travel towards open, the next activation will cause the trolley to travel to the closed position and reengage, subsequent operations will move the door.

Questions??

For quick answers and helpful advice, call
Wayne-Dalton Customer Service
(888) 827-3667