



www.wayne-dalton.com


idrive[®]

for Torsion Springs

Update Revision Label

IMPORTANT!

You **MUST** replace revision label when upgrading the MCB (Motor Control Board) of the Torsion idrive[®] opener.



Locate and remove the existing revision label (yellow label) on the bottom side of the Torsion idrive[®] opener; replace with the new revision label provided with the MCB (Motor Control Board). **NOTE:** Only replace the revision label if the new revision label is higher than the current revision label.